



# ROD STRETCH CALCULATION CHART

keep it moving 



## PROCEDURE:

Total head → Pump series → Rod size → Setting depth → Rod stretch



Axial load

## SPACE OUT CALCULATION:

Rod stretch + stopb bushing + safety margin = total space out